








DL/DL-DALI/DL-DIM/ SL/SL-ACK/SL-DALI+ACK




MOUNTING INSTRUCTIONS FOR JOINTS



DL / SL Joint Cover

Unpainted	1015520
Painted	2054580

This product is sold separate from busbar.



■ The busbar should be in flatwise position.